

## Zestaw montażowy

Nr. katalogowy

**0547**



### PEUGEOT

304,31 78-90  
405 06.87-

### RENAULT

R21 03.86-04.95  
Escape 01.91-12.95  
Safrane 04.92-01.95

### TALBOT-SIMCA

150,1100 -05.82  
1307,1308,1309 -82  
1508,1509,1510 -05.82  
1609,1610 -08.84  
Alpine,Rancho,Solara 70-01.86

### VOLVO

340,345 81-89  
360 83-89

φ 228.6 x 45 GIRLING